

ENGLISH

More informations at:
<http://service.admonter.at>



CLEANING INSTRUCTIONS

CLEAN AND CARE





CLEAN AND CARE - GENERAL REQUIREMENTS

Sweep all dust and dirt off the floor before undertaking any care or maintenance procedures.

If there is more dirt on the floor use Admonter Clean & Care (shake well before use!) and add approx. 100 ml to 10 litres warm water and wipe the floor in the direction of the grain, using a damp mop.

We recommend using two buckets – one for the care product and the other for clean water to rinse the mop.

EASY CARE SURFACE

The easy care surface is already factory finished with an additional coat of oil, therefore no final coat of oil is required after installation!

MAINTENANCE (REOILING) - NATURAL-OIL-SURFACE

Depending on the amount of foot traffic, oiled floors will need to be re-oiled periodically.



Depending on the amount of foot traffic, oiled floors will need to be re-oiled periodically. Admonter maintenance oil natural clear shake well before use! Should be used sparingly (1 litre is sufficient for approx. 70 – 100 m²). Distribute the oil evenly with the use of an oil-sponge, soft cloth or spray can. The quantity of maintenance oil natural clear applied may vary due to the different absorption of the wood. Polish the floor using a polishing machine and a white pad (different colour pads may be used depending on 3M products).

Small areas can be treated by hand using a white polishing pad or a soft cloth. Polish thoroughly. Do not apply the oil thickly. Ensure an even distribution of the oil in order to avoid differences in the overall shine once the floor has dried.

Allow the floor to dry for approx. 24 hours, taking extra care during this period to prevent any contact with moisture.

Depending on the polishing, the room temperature and the moisture level the drying of the floor can take 2 - 7 days. Please allow air to flow into the room and combine with underfloor heating to help dry the floor faster. During this period you can walk on with clean slippers, avoid any dirt!

Cover high traffic areas with cardboard. Do not clean the floor for the first 8 – 10 days, thus allowing the surface to harden completely. After use, oil-saturated cloths must be soaked in warm water and then hung out to dry (Caution: could be flammable).



UV OILED FINISH (WE RECOMMEND)

For initial care, add approx. 100 ml of Admonter Clean & Care (shake well before use!) to approx. 10 litres warm water and wipe the floor in the direction of the grain, using a damp mop. For a shinier finish, allow the floor to dry for approx. 30 minutes and polish using a white pad or a soft cloth. We recommend treating a brushed UV oiled floor with Admonter maintenance oil, especially in high traffic area and commercial projects (see initial care & maintenance of natural oiled surfaces).

MATT LACQUER FINISH (WE RECOMMEND)

After installation add approx. 100 ml of Admonter Clean & Care to 10 litres warm water and wipe the floor in the direction of the grain, using a damp mop. Allow the floor to dry.

After the floor has dried the floor can be polished by hand or using a polishing machine.

REGULAR CARE & MAINTENANCE



Add approx. 100 ml of Admonter Clean & Care natural clear to 10 litres warm water and wipe the floor in the direction of the grain, using a damp mop (around 1000 ml when the colour has faded or the floor looks dull).

We recommend using two buckets – one for the care product and the other for clean water to rinse the mop.

For a shinier effect allow the floor to dry for approx. 30 minutes and polish using a white pad* or soft cloth.

* different colour pads may be used depending on 3M products

PLEASE NOTE

- For care and maintenance of high traffic areas, please refer to our specific guidelines!
- Reconditioning and local repairs should only be done by flooring professionals!

ENGLISH

More informations at:
www.admonter.eu/en/downloads

Admonter 
NATURE'S FAVOURITE DESIGNER



MORE
INFORMATIONS AT

www.admonter.eu

ADMONTER

Holzindustrie AG
8911 Admont - Austria

info@admonter.at
www.admonter.eu